

Rush

Customer/Bill to: _____

Collected by (name): _____

Phone: _____ Email: _____

Sample Address: _____

Address/WSSN#: _____

Date Sampled: _____ Time Sampled: _____ am / pm

Sample Point A: _____ Site Code: _____

Sample Point B: _____ Site Code: _____

Chlorine: Y / N _____ Transported on Ice:

Reason for testing: Real Estate / Routine / Repeat / Repair / Water Quality / Other _____

Do **NOT** test if compliance requirements are not met:

Notes/Copy Report to: _____

Testing Requested:

- | | |
|--|--|
| <input type="checkbox"/> Bacteria <small>(Coliform, E.coli)</small> | <input type="checkbox"/> Colony Count |
| <input type="checkbox"/> Basic Pkg. <small>(Coliform, E.coli, Nitrate, Nitrite)</small> | <input type="checkbox"/> Nitrate/Nitrite |
| <input type="checkbox"/> Arsenic | <input type="checkbox"/> VOC |
| <input type="checkbox"/> Lead | <input type="checkbox"/> Partial Chemistry |
| <input type="checkbox"/> Comprehensive Pkg. <small>(Coliform, E.coli, Nitrate, Nitrite, Arsenic, Lead, Sodium, Hardness)</small> | |
| <input type="checkbox"/> Other: _____ | |

Relinquished By: _____ Received By: _____

FOR LAB USE ONLY		Received Temp: _____ °C	
Analyzed: _____		Analyzed: _____	
Coliform: _____	E.coli: _____	Nitrate: _____	Nitrite: _____
Analyzed: _____		Analyzed: _____	
Arsenic: _____	Lead: _____	Sodium: _____	Hardness: _____
		Inv	Rep

www.aquatestlabs.com / info@aquatestlabs.com / (248) 698-9500

Chain of Custody

Ref#

Sample #:

General Sampling Instructions

For best results: Choose a drinking water tap inside the house. If possible avoid a single lever faucet or a pull out sprayers. Sample should be from cold water only, and remove the aerator from the faucet. Please note in most cases sampling from laundry tubs or outside spigots are not recommended.

Bacteria test: Use the clear round bottle with a printed seal. Do not open until ready to collect the sample. This bottle contains a chlorine neutralizing tablet do not rinse. To avoid contamination, do not set the cap down, touch the lip or inside of the bottle. This sample must be tested within 30 hours of collection.

1. Sanitize the faucet and flush for 3 to 5 minutes.
2. Run water at moderate rate to limit splashing.
3. Fill the bottle to the 100 ml etch line. Do not over fill.

Nitrate & Nitrite test: Use the opaque rectangular bottle. This sample must be tested within 48 hours of collection.

1. Flush the faucet for 3 to 5 minutes.
2. Fill the bottle to the top.

Arsenic, Lead* or other*: Use the opaque rectangular bottle.

1. Flush the faucet for 3 to 5 minutes.
2. Fill the bottle to the top.

* May require special procedure for compliance, call if you have questions.

**After collection immediately store in refrigerator and /or transport in a cooler with freezer packs. Fill the front of this form completely. Return the samples and form as soon after sampling as possible to:
9165 Highland Rd.; White Lake, MI 48386
Monday - Friday 9AM to 430PM or Dropbox**

If you are shipping samples ensure they are packaged appropriately and ships the same day.

Please allow 2 business days for results. Reports are sent via email unless requested otherwise.

Terms & Conditions

By using this service, you agree to be bound by Aquatest Laboratories terms and conditions. Complete language can be found on our website or by request. When using these services you shall be subject to any rules applicable. Any participation in this service will constitute acceptance of this agreement.

www.aquatestlabs.com / info@aquatestlabs.com / (248) 698-9500